

Pulling Ecoflex

Step 1



Pipe ends must be covered at all times.

Step 2



Remove the cone from the end of the Ecoflex. Make sure the carrier pipe is visible.

Step 3



Using a drill with a 1/2" drill bit, drill a hole vertically through the Ecoflex, 12 inches from the end of the pipe. Make sure the drill bit goes through both sides of the jacket as well as the carrier pipe.

Step 4



Using the same 1/2" drill bit, drill a hole through the top of the cone.

Step 5



Thread one end of the rope through the top of the jacket and out through the carrying pipe. Take the part of the rope coming out of the jacket and wrap it once around the pipe, then thread it through the adjacent hole and out the carrying pipe. Thread both ends through the hole into the top of the cone.

Step 6



Put the cone back on the end of the pipe and tape it in place.